

## Installation for ceramic and natural stone tile:

- Follow ceramic and natural stone tile manufacturer's recommended installation instructions.
- Installation and subfloor requirements must conform to TCA or TCC standards.
- Concrete subfloors must be dry, clean and free of dirt, grease, wax, paint, oil or anything that would adversely affect adhesion of **DURAQUIET**.
- Subfloor must be checked for excessive moisture. If a waterproof membrane is required specify:
  - Redgard
  - Tech Hydraflex.
- Areas requiring fill patching or levelling must be prepared by general contractor using a self-levelling underlayment.
- Install a perimeter isolation strip or foam to the wall perimeter of the entire subfloor, as well as around the perimeter of any protrusions.
- Adhere **DURAQUIET** substrate using a urethane based adhesive, butt the edges together, making sure not to overlap the membrane.
- Immediately roll the floor using a 50-75 lb. roller to ensure proper adhesive transfer. Roll the width first, then the length.
- Apply selected dry-set mortar over **DURAQUIET**, as directed by mortar manufacturer.
- Grout tiles using a polymer modified grout or a 100% solids epoxy grout.

## Installation for vinyl floor:

- Follow vinyl manufacturer's recommended installation instructions.
- Concrete subfloors must be dry, clean and free of dirt, grease, wax, paint, oil or anything that would adversely affect adhesion of **DURAQUIET**.
- Subfloor must be checked for excessive moisture. If a waterproof membrane is required specify:
  - Redgard
  - Tech Hydraflex.
- Areas requiring fill patching or levelling must be prepared by general contractor using a self-levelling underlayment.
- Adhere **DURAQUIET** substrate using a urethane based adhesive, butt the edges together, making sure not to overlap the membrane.
- Immediately roll the floor using a 50-75 lb. roller to ensure proper adhesive transfer. Roll the width first, then the length.
- Seal **DURAQUIET** with a moisture cured urethane adhesive.
- Glue down the vinyl tile or floor to **DURAQUIET** with an acrylic adhesive recommended by the vinyl manufacturer.

**GYP-CRETE UNDERLAYMENT MUST FIRST BE SEALED WITH SPECCO S-55 BEFORE YOU APPLY ANY MOISTURE CURED URETHANE ADHESIVE**



Distributors

**HEAD OFFICE**  
Dura Undercushions Ltd.  
8525 Delmeade Road  
Montreal (Quebec) H4T 1M1  
Tel. : 514-737-6561  
800-295-4126  
Fax : 514-342-7940  
E-MAIL : info@dura-undercushions.com  
Web site : www.duraquiet.com