

SUPER DURA

Installation guideline

1. Make sure the subfloor is clean and dry.
2. Cushion should be laid rubber-side down in the longest lengths possible.
3. Cushion seams should be at right angle to carpet seams: where this is not possible they should at least be six inches from the carpet seams.
4. Butt the cushion seams, and effect tight, even seams.
5. Tape all the seams with duct tape.
6. Trim excess cushion at perimeter of the room.
7. Carpet should be prepared and installed in accordance with the manufacturer's recommendations.